


Embossing direction

For **round** seal presses, there are **four** different directions possible to affix the die, from the bottom, from the top, from the right or from the left.

For **square** seal presses, **two** different directions are possible, from the bottom or from the top.

On the illustration below, you can see on what position of the paper **the impression** should appear.

Choose your desired embossing direction and the die will be affixed accordingly on the seal press.



If you have any further questions, please contact
our free hotline: **1-844-712-0175**
or email to: **info@getstamps.ca**